

NATURALLY PERFECT INDOOR PROTECTION

There is nothing warmer and more inviting than the comfort of wood in your home. Sansin Purity Interior Stains and Clears are designed to bring the natural beauty of your wood to life.

Sansin Purity Interior Clear and Sansin Purity Interior Stain: Preparation

- Remove all hardware; cover hardware that cannot be removed with masking tape.
- Clean all surfaces using Sansin Multi-Wash to remove grease, oil and dirt. Use a damp cloth or sponge to remove any residue from surfaces. Allow to dry.
- Repair any surface defects such as holes and cracks, using only quality acrylic-based tinted wood fillers to match the color of the project. Wood filler must be allowed to dry completely prior to sanding.
- Proper sanding will make for a more beautiful finish. Sand using 80–120 grit paper using random orbital sanders. Always sand with the grain for best results; do a follow-up sanding with 150–180 grit sandpaper if necessary. Remove sanding dust by vacuuming and then wiping with a damp cloth to remove all dust particles.

Sansin Purity Interior Stain: Application

- Apply PURITY INTERIOR STAIN using a premium china bristle brush, pad applicator or spraying followed by back brushing. Always ensure a uniform saturated coat is applied to the wood. Allow 24 hours drying time in proper conditions [temperatures of 15–20°C (59–68°F) with relative humidity no higher than 70%.] Always allow complete drying prior to applying a second coat.
- For a deeper color a second coat of interior stain may be required. Allow a drying time of 24 hours in proper conditions.

Sansin Purity Interior Clear: Application

- Apply the first coat of PURITY INTERIOR CLEAR UV or PURITY INTERIOR CLEAR ARCTIC by spraying; or use either a China bristle or nylon polyester brush respectively, or use a pad applicator. Which application method is best for you depends on the type and size of surface. Apply finish consistently. PURITY INTERIOR CLEAR has excellent leveling properties; be careful not to overwork the product.
- Purity Interior Clear formulas require two or three applications for uniform sheen and film. For best results and optimum clarity use the respective Gloss formula for the first two coats and the desirable sheen formula (Gloss, Satin, or Flat) for the final coat.
- Allow 6 hours drying time in proper conditions. Proper conditions require temperatures of between 59–68°F (15–20°C) with relative humidity no higher than 70%. Always allow complete drying prior to re-coat.
- After surface is completely dry, sand using 220–320 grit sandpaper or a fine synthetic abrasive pad. Sand with direction of grain.
- Vacuum the surface and follow by wiping with a damp cloth to remove all dust particles.
- Apply the second coat of the selected PURITY INTERIOR CLEAR formula.
- For additional protection or gloss a third coat may be applied after 6 hours or when surface is completely dry.

Cont'd on reverse ...



Purity Interior Stain: Coverage

With each application Purity interior Stain has an average coverage of 200 sq. ft. (18.58m²) per US gallon (3.78L). Purity Stain is normally only applied as a single coat application.

Purity Interior Clear: Coverage

Purity Interior Clear formulas have an average coverage of 400 sq. ft. per gallon.

Cleanup

Clean hands and tools with soap and water.

Maintenance

Sansin Purity Interior Stains and Clears are virtually maintenance-free. Surfaces damaged as a result of heavy abrasion, denting or scraping can be restored to their original beauty with just a touch-up coat. Simply prepare the area by sanding before applying the appropriate Sansin Purity Interior formula as per product directions.

S A N S I N[®]Naturally Perfect[®]